

Instruction Manual

Electronic Insect Killer

The Electronic Insect Killer utilizes the black light (ultra-violet rays) of the wave length, which is proved to be the most effective lure for light sensitive flying insects, such as flies, moths, mosquitoes, and other flying insects. These insects are electrocuted upon touching the inner high voltage grids. No chemicals, no smell, no sprays, no mess, pollution free and harmless to humans and pets. It is ideal for using in houses, office, factories, food outlets, hospitals and other places.

WARNINGS:

1. Household use only! Suit for indoor and outdoor use.




2. High voltage! Do not touch the inner electric grids.
3. Never put metal objects inside the grids while in operation.
4. Keep away from flammables.
5. Check the local voltage before operating.
6. Hang or ceiling on a place where children cannot reach.
7. Keep the appliance and its cord out of reach of children.
8. Children cannot play with it. Children should be supervised to ensure that they do not play with the appliance.
9. The Insect Killer cannot be used in barns, stables and similar locations.
10. The appliance is not to be used in locations where flammable vapor or explosive dust is likely to exist.
11. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
12. Unplug the appliance before cleaning. Clean the plastic enclosure/ grille with dry clothes empty the collection tray every week or when need.
13. The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
14. Keep the appliance and its cord out of reach of children less than 8 years.
15. **WARNING:** An electric shock hazard may exist if water from a garden hose is directed at the Insect Killer. When using extension cord, keep the socket-outlet away from moisture and avoid damage to the cord.
16. **The compulsory cautions:** "This appliance is not intended for use by

persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety"

Main Power: AC220V-240V 50/60Hz

Explosive View:



DISPOSAL: Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

This product must not be disposed together with the domestic waste. This product has to be disposed at an authorized place for recycling of electrical and electronic appliances.

By collecting and recycling waste, you help save natural resources, and make sure the product is disposed in an environmental friendly and healthy way.